

PRE-FINISHED PLYWOOD AND PANELS

SOUDAL

Plymasters has partnered with Soudal to provide the best recommendations for fixing our panels to **timber framing/battens** and **uncoated timber walls**.

PLYMASTERS APPROVED PANELS

- Classique Birch Pre
- Classique Canadian Oak Pre.



SOUDAL GLUE RECOMMENDATIONS

- Gorilla FixALL Flexi
- Gorilla FixALL High Tack
- Soudal Soudaseal 240FC

PREPARATION

Wipe the back of the prefinished panel with a solvent wipe.
Allow to evaporate completely from surface.
Ensure that walls/ framing/ battens are straight and level.

APPLICATION

Apply 8mm x 8mm beads x 300mm length every 500mm down every framing stud or batten. Compress to 2mm minimum thickness.

FIXING Mechanically fix in place with appropriate panel pins.

**WHATEVER THE JOB
WITH SOUDAL,
YOU'RE UP TO IT.**

SOUDAL
GORILLA
UP TO IT.