

UNCOATED PLYWOOD AND PANELS

SOUDAL

Plymasters has partnered with Soudal to provide the best recommendations for fixing our panels to **timber framing/battens** and **uncoated timber walls**.



PLYMASTERS APPROVED PANELS

Marine Gaboon BB/CC, Keruing
Brownwood, Merani, NZ Pine

SOUDAL GLUE RECOMMENDATIONS

- Gorilla Grip 2 Hr Cure
- Gorilla Grip 1 Hr Cure

PREPARATION

Lightly dampen the surface with water to improve adhesive bond. Ensure that walls/ framing/ battens are straight and level.

APPLICATION

20mm blobs of Gorilla Grip every 500mm down every framing stud or batten.

FIXING

Mechanically fix in place with appropriate panel pins.

