

Contact

SOUDAL NZ LTD

134 Kohia Drive, Horotiu, 3288
Hamilton, New Zealand
Ph: 0800 70 10 80
Email: sales@soudal.co.nz
www.soudal.co.nz




4 & 6 Line

Retracting Clothesline

4 Line - 99157530, 99157349

6 Line - 99157547, 99157356



Introduction

Congratulations

Congratulations on the purchase of your Sun King Retracting Clothesline, which will bring you many years of trouble free and efficient drying. It's important that you read this Product Manual thoroughly before installation to benefit from the design features and enjoy safe use of this product. Thank you for choosing Sun King.

Warning

- Do not allow children or pets to swing on the Clothesline or items of laundry.
- Do not use for any purpose other than to hang and dry washing.
- Do not use your Clothesline if parts are worn or damaged.
- Do not operate the locking lever when the arm is located in the cabinet.
- Do not release the locking mechanism when there are clothes attached to the lines.
- Do not allow the arm and lines to retract uncontrolled as this may lead to personal injury or property damage. Hold the arm securely and walk it back to the cabinet.

Warranty

In addition to all rights and remedies to which you may be entitled under the New Zealand Consumer Guarantees Act (1993) and any other relevant legislation, Soudal NZ Limited warrants the product to be free from defects in materials or workmanship for 10 years from the date of purchase.

In the event of a claim, you must take the product with proof of purchase and an explanation of the fault to the place of purchase or contact Soudal NZ Limited and provide your proof of purchase. All costs associated with the return of the good (and other expenses incurred in claiming under this warranty) are your responsibility. We will, at our option, either repair or replace the product if it has a defect in its materials or workmanship.

Soudal NZ Limited liability under this warranty is subject to Soudal NZ Limited being satisfied that a defect was caused by defective workmanship or materials and was not caused by or substantially contributed to by other factors including (but not limited to) maintenance or repair, adjustments or modifications of the product in a manner not recommended by the manufacturers or any neglect, misuse or excessive use. For the avoidance of doubt, this warranty does not cover acts of God, earthquake, cyclone, fire, explosion, flood, landslide, lightning, storm, tempest, drought or meteor, war, terrorism, restraint or damage to property by or under the order of any government authority or industrial action.

You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For goods purchased within New Zealand, this warranty is provided by Soudal NZ Limited, 134 Kohia Drive, Horotiu, Hamilton. Phone 0800 70 10 80.

WARNING: Ensure the lines are not under tension before releasing the arm.

7.4 To unlock and release tension of the lines

With all clothes and washing removed from the lines; pull out and unlatch the locking lever from its locked position. Rotate anti-clockwise to its unlocked position (**Fig. 14**).

Do not let go of the locking lever as it may return with some force.

7.5 To remove the arm from the receiving bracket

Rotate, guide and lift the arm up and out of the receiving bracket (**Fig. 15**).

WARNING: The lines are under spring tension. **Do not** allow the arm and lines to retract uncontrolled as this may lead to personal injury or property/product/damage. Hold the arm securely and walk it back to the cabinet.

Fig. 14






Fig. 15




Package Contents



6 Line Retracting Clothesline

Item	Part Name	Quantity
1	6 Line Retracting Clothesline	1
2	Receiving bracket	1



4 Line Retracting Clothesline

Item	Part Name	Quantity
1	4 Line Retracting Clothesline	1
2	Receiving bracket	1

Mounting Options

Optional Mounting Kits

If you choose to mount your Retracting Clothesline cabinet or receiving bracket on posts, the following products are available to purchase separately:

Optional Mounting Kits:

Mount Bar 4 - Item Code 99157363.


Mount Bar 6 - Item Code 99157370.

Post Kits:

Post Kit - Item Code 99157387.

Mounting

Determine which of the four mounting options most suits your requirements.



Wall to Wall



Wall to Post

Requires:
1x Post Kit



Post to Wall

Requires:
1x Post Kit
1x Mount Bar



Post to Post

Requires:
2x Post Kit
1x Mount Bar

Note: Minimum operating distance is 4m (13'). Maximum operating distance is 6.5m (21'4").

7.3 To tension and lock the line

With the arm engaged correctly in the receiving bracket, rotate the locking lever (on the right hand side of the cabinet) (Fig. 12). Rotate clockwise from the unlocked position until it locates in the first lock position. This provides normal tension on the lines (Fig. 13). Check the product is locked by pulling firmly on the lines. If you require extra tension on your lines, rotate the locking lever further, until it locates in the second lock position (Fig. 13).

Fig. 12





Fig. 13

If extra tensioning is required, move the locking lever to the 2nd lock position.




WARNING: If your unit is mounted at 4m distance **do not** use the second lock position.

7.2 To attach the arm and line assembly to the receiving bracket

Grip the arm with each hand either side of the receiving bracket. Centre the arm within the receiving bracket. Rotate and guide the arm downwards into the receiving bracket. This means the arm has engaged. (Fig 11).

Fig. 11




Installation Location

Step 1 - Select a suitable location

- 1.1 Select a suitable location for either wall or post mounted installations.
- 1.2 This product has been designed to mount and operate between 4m (13') and up to 6.5m (21' 4").
- 1.3 Always leave approximately 1.5m (5') clearance each side of the line and any wall fence/shed etc.

Note: This product must only be installed on sound structural walls. Do not mount directly onto cladding materials. If you have any doubt, contact your local hardware store or installer.




Installation

Step 2 – Recommended installation height


- 2.1** For all installations, we recommend the operational height for the line is approximately 50mm (2") above the user's head height.
- 2.2** For the heights and combinations of wall/post installations refer to the appropriate details below.

Wall Installation



Note: The receiving bracket should be located at a height to ensure the clothesline is close to horizontal.

Post Installation




Note: The receiving bracket should be located at a height to ensure the clothesline is close to horizontal

Operation

Step 7 - To extend the arm and line assembly

- WARNING: Do not** operate the locking lever when the arm is located in the cabinet.
- WARNING: Do not** release the locking mechanism when there are clothes attached to the lines.
- 7.1** Remove the arm from the cabinet by pulling on the two end caps. Holding the arm firmly, extend it towards the receiving bracket (**Fig. 10**).

Fig. 10



Step 6 – Mounting your receiving bracket to a post

6.1 Prepare your receiving bracket location


On the pre-determined product centre, locate the position for your post and receiving bracket (refer to page 4).

6.2 Install your post as per the instructions supplied with your post kit. Refer to diagram on page 5 to determine the installation height of your post. Refer to page 2 for the post kit available.

6.3 Secure the receiving bracket to a post

Using the fasteners supplied with your post kit attach the receiving bracket to the post kit assembly (Fig. 9).

Fig. 9



Step 3 – Mounting your cabinet to a wall

3.1 Prepare your cabinet location

Determine the best location for the installation of your product (refer to page 4).

Mark out a centre line for your product within your allocated site.


3.2 Ensure that either side of this centre line and the area where the cabinet is to be installed on the wall is free from pipes and other obstructions (Fig. 1).

3.3 Mark the cabinet mount centres on the wall at the desired installation height (refer to page 5 and the table below).

Fig. 1

Mount Hole Centres

Product	Centres (mm)	Centres (inch)
6 Line	814	32
4 Line	570	22 1/2




3.4 Drill holes in wall

Masonry fasteners are **not** included with this product. When attaching to a sound masonry wall, we recommend using masonry sleeve anchors (diameter 10mm x 55mm).

3.5 If you are using these fasteners, drill a $\varnothing 10\text{mm}$ (13/32") hole using a masonry drill (Fig 2).

Note: If you are mounting to a different wall type, consult your hardware store for advice on the appropriate fasteners to use.

Fig. 2



3.6 Secure your cabinet to the wall

Remove the end covers using a Phillips head screwdriver. (Fig. 3).

3.7 Ensure square metal locking rod does not come out of the cabinet.

3.8 Locate the cabinet with the mount holes. Insert masonry fasteners and secure (Fig. 4).

3.9 Re-attach cabinet end covers (Fig. 4). Do not overtighten the screws.

Fig. 3





Fig. 4



Step 5 – Mounting your receiving bracket to a wall

5.1 Prepare your receiving bracket location

Mark the mount hole centres on your pre-determined centre line at the desired height (refer to page 5). Ensure there are no pipes or obstructions in the surrounding area.


5.2 Drill holes in the wall

Refer to page 6 for instructions on drilling holes and appropriate fasteners.

5.3 Securing your receiving bracket to the wall

Insert the masonry fasteners (not included with this product) and secure. (Fig. 8).

Fig. 8



4.5 Secure your cabinet to a post

Remove end covers using a Phillips head screwdriver (Fig. 6).

4.6 Ensure square metal locking rod does not come out of the cabinet.

4.7 Locate the cabinet with the pre-drilled holes in the mount bar (sold separately). Using the fasteners and instructions provided with the mount bar kit, secure the cabinet to the post assembly (Fig. 7).

4.8 Re-attach cabinet end covers (Fig. 7).

Fig. 6





Fig. 7



Step 4 – Mounting your cabinet to a post

4.1 Prepare your cabinet location

Determine the best location for the installation of your product. Mark out a centre line for your product within your allocated site.

4.2 Determine your post locations. Install as per the instructions supplied with your post kit.

4.3 To post mount your cabinet you will need to purchase a matching mount bar kit (refer to page 3).

4.4 Attach the mount bar to the post as per instructions supplied with your mount bar kit.

Fig. 5

